

ESC-0391-93-01

Lib.# 01067

Micromite™ II Service Manual



THERMO ELECTRIC

PART #E2295
August, 1987

contents

introduction	how to use this manual 1
section 1	maintenance
1-1	general maintenance 3
1-2	troubleshooting guide 3
section 2	recalibration procedure 9
2-1	introduction 9
2-2	equipment required for recalibration 9
2-3	entering calibration mode 10
2-4	exiting calibration mode 10
2-5	important procedural information 11
2-6	battery calibration 12
2-7	millivolt calibration 13
2-8	RTD calibration 14
2-9	RJC calibration 14
section 3	warranty 16
section 4	instrument service 18
section 5	specifications 20
section 6	schematics & parts lists 24



how to use this manual

This manual should be used in conjunction with the Instruction Manual furnished with the Micromite II. The **Instruction Manual** contains all the information you will need to *operate* the Micromite II and this **Service Manual** contains the information you will need to *recalibrate* the instrument.

In addition to the recalibration procedure, complete schematic drawings and parts lists, we have included some information from the Instruction Manual to familiarize you with the Micromite II.

You will find general information on Micromite II, the Portable Temperature Laboratory, optional accessories, the Micromite II product code, maintenance, service and warranty information and complete Micromite II specifications in this manual.

We recommend you read through this information carefully. If you have a problem, you may find that referring to the troubleshooting guide will help you solve the problem, without requiring any further procedures.

Should you want to recalibrate the Micromite II to insure it remains within spec, please see that only qualified technicians with the proper equipment attempt this recalibration, or any other service procedures on the Micromite II. As you will see, calibrating the instrument does not require opening

section 1

the case and, unless the instrument is abused or damaged during the calibration process, it should not affect the warranty.

However, attempting to service the Micromite II in any other way may void its warranty. We recommend you return the Micromite II to Thermo Electric for service. Please refer to the "section 4, instrument service" for details.

Section 3 of this manual, Thermo Electric's warranty, the Micromite II for the time period specified in material and workmanship for a period of 2 years and Thermo Electric's liability is limited to the repair or replacement of the instrument and its accessories, during the warranty period and nothing in this manual shall be construed to affect or constitute a limitation on the right of the user to sue for damages.

It is the policy of Thermo Electric to provide a high level of customer service and to ensure that the instrument is returned to the user in the shortest possible time. The instrument is returned to the user in the shortest possible time.

While the instrument is in the factory, it is subject to the same conditions as the instrument in the field. The instrument is subject to the same conditions as the instrument in the field. The instrument is subject to the same conditions as the instrument in the field.

Section 2: Instrumentation

The following is a list of the instruments and their specifications. The instruments are listed in the following order: 1. Instrumentation, 2. Specifications, 3. Instrumentation, 4. Specifications.

If you are unable to perform the service, please refer to the "section 4, instrument service" for details.

The first step in the process of creating a new product is to identify a market need. This is often done through market research, which can involve surveys, focus groups, and other methods of gathering information from potential customers.

Once a market need has been identified, the next step is to develop a product concept. This involves creating a detailed description of the product, including its features, benefits, and target market. The product concept is then used to create a business plan, which outlines the company's strategy for developing and marketing the product.

section 1 maintenance

1-1 general maintenance

Under the terms of the warranty (discussed fully in Section 3 of this manual), Thermo Electric warrants the Micromite II to be free from all defects in material and workmanship for a period of two years... and Thermo Electric's liability is limited to the repair or replacement of the product only if failure occurs during the warranty period *and factory inspection shows no external effects or customer repair altered the functioning of the instrument.*

As the Micromite II is a complex and sophisticated electronic instrument and you risk voiding your warranty under the terms described above, any repair or replacement of parts should be attempted only by technically qualified individuals.

While recalibration of the Micromite II *can* be done in the field if you have the appropriate equipment (See section 2-2, page 13), and qualified personnel, we strongly recommend you return the Micromite II to Thermo Electric for any other service that may be required.

1-2 troubleshooting guide

The following is a basic troubleshooting guide which can be used to help identify and correct problems that may occur with the Micromite II.

If you are unable to perform these checks or they do not correct the problem, you can call a Thermo

Digitized by the Internet Archive
in 2025

https://archive.org/details/manualsplus_06977

Electric Instrument Service Representative at the factory, (201) 843-5800, who may be able to help you resolve the problem over the phone.

If the problem still cannot be resolved, the Micromite II should be returned to the factory or to a Thermo Electric Instrument Service Center for repair. If this is necessary, please follow these instructions:

- 1 Pack the Micromite II carefully, to prevent shipping damage.
- 2 Include a brief note with a description of the problem and your company's name, address, phone number, your name and any other identifying data required to contact you and return the instrument.
- 3 If you don't know the location of your nearest Instrument Service Center, call your Thermo Electric representative or your nearest Thermo Electric Regional Office. A list of these Regional Offices is included in Section 4 of this manual.
- 4 Send the Micromite II, prepaid, to the nearest Thermo Electric Service Center or to the factory:

Thermo Electric Co.
109 North 5th Street
Saddle Brook, NJ 07662
Attn: Instrument Service Department

- 5 If you're sending the Micromite II to the factory, please call first to obtain a Material Return Authorization (MRA) number. Be sure to place that number on the outside of the carton in which you ship the instrument.


Symptom	Possible Cause	Corrective Action
No display (Micromite II will not turn on)	Dead batteries.	Replace batteries or use AC adapter.

Symptom	Possible Cause	Corrective Action
	Batteries not inserted properly or dirty battery terminals.	Check polarity of batteries and clean terminals.
	AC adapter not plugged into instrument or wall properly.	Check connections. Try another outlet.
Display indicates: Reset! Please turn off	Instrument turned off by removing power (e.g. unplugging adapter while instrument is on, power failure or removing batteries while instrument is on).	Turn instrument off and on again. Sensor will default to Type J. See Section 2-3, page 11 of the Instruction Manual.
	Input wires and/or instrument may be too close to an EMI/RFI source (e.g. a large inductor or RF transmitter).	Place input wires and/or instrument some distance from interference source to prevent noise pick-up. Turn instrument off and on again. Sensor will default to Type J.
	If using adapter, may be using wrong adapter or line voltage may be too low or occasionally dipping.	Make sure AC adapter is specified for your line voltage. Try using line conditioner or operate instrument on batteries.
		If, after checking the above, this display continues, return for service.
Display indicates: Sensor is open!	Possible open input circuit or broken thermocouple lead.	Check sensor and terminal wires.

Symptom	Possible Cause	Corrective Action
	"+" and/or "-" knobs may not be fully tightened.	Tighten knobs. Do not overtighten.
	If sensor type is RTD or Ω , leads may be broken or connected incorrectly.	Check RTD leads. If they are functional, refer to Section 2-6, page 16 of the Instruction Manual.
Input indication is incorrect	Thermocouple, RTD or copper wires may be connected backwards or incorrectly.	Refer to Section 2-6, page 16 of the Instruction Manual.
	Instrument may be in output mode instead of input mode.	Return instrument to input mode. Refer to Section 2-7, page 24 of the Instruction Manual.
	Instrument is set for wrong sensor type.	Refer to Section 2-5, page 12 of the Instruction Manual.
	Thermocouple is defective.	Verify correct instrument operation by placing it in any thermocouple range, except Type B. Short the input. If the instrument is working properly, it should indicate room temperature.
	RTD is defective.	Verify correct instrument operation by trying another known working RTD or resistance.
	Poor thermocouple or RTD placement.	Verify thermocouple or RTD placement at measuring point.

Symptom	Possible Cause	Corrective Action
Incorrect output	Thermocouple or copper lead wires may be connected backwards or incorrectly.	Refer to Section 2-7, pg. 18, Instruction Manual. If RTD or Ω output does not work, refer to Section 2-7, RTD output, page 19 of the Instruction Manual. RTD/ Ω output is wired <u>differently</u> than RTD/ Ω input.
	Instrument is set for wrong sensor type.	Refer to Section 2-5, page 12 of the Instruction Manual.
	Instrument is in input instead of output mode.	Enter output mode. Refer to Section 2-7, page 18 of the Instruction Manual.
	Possible broken leads or connecting wire.	Check leads or use known working leads.
Input indication jumps when in input mode or output signal jumps when in output mode	"+" and/or "-" knobs may not be fully tightened.	Tighten knobs. Do not overtighten.
	Input/output wires and/or instrument may be placed too close to EMI/RFI source (e.g. a large inductor or large RF transmitter).	Place input/output wires and/or instrument some distance from interference source to prevent noise pick-up.
		Shield input/output wires.
	If in output mode, output may not yet be settled.	Allow time for settling. Refer to specs in Section 5.
	"+" and/or "-" knobs may not be fully tightened.	Tighten knobs. Do not overtighten.

Symptom	Possible Cause	Corrective Action
None	If using adapter, may be using wrong adapter or line voltage may be too low or occasionally dipping.	Make sure AC adapter is specified for your line voltage. Try using line conditioner or operate instrument on batteries. If problem persists, return instrument for service.



section 2

recalibration procedure

2-1 introduction

The Micromite II has several precision internal references. When the instrument is calibrated, these internal references are accurately measured by one of the Micromite II's microprocessors. The values of these references are then permanently stored in the unit's memory.

During normal use, the Micromite II automatically recalibrates its own circuitry against these "known" references approximately every 15 seconds. This unique method of calibration gives the Micromite II its high accuracy, stability and repeatability.

Since the Micromite II is calibrated at the factory before shipment, it will give you precise, accurate results immediately. However, over time, the value of the internal references may change slightly as a natural result of aging. As this process varies from instrument to instrument, we recommend that your Micromite II be tested and, if necessary, be recalibrated every six months to insure that it meets its specified accuracy.

The Micromite II should be tested and/or recalibrated only by qualified personnel with the appropriate equipment as specified below.

2-2 equipment required for recalibration

- Adjustable mV standard, 0 to 99.000 mV, 0.0001 mV resolution, with an accuracy of ± 0.0005 mV

- Low EMF and low resistance shorting terminal (gold or copper) or 0.0000 mV standard, with an accuracy of ± 0.0005 mV
- 400.000 Ω resistance standard, with an accuracy of ± 0.005 Ω
- Stirred ice bath (32.0°F), with an accuracy of $\pm 0.05^\circ\text{F}$
- ISA J precision reference thermocouple with a known error at a temperature differential between room temperature and ice (32.0°F), with an accuracy of $\pm 0.05^\circ\text{F}$ (± 0.001 mV)
- Adjustable power supply (5.0 – 9.0 volts @ 100 mA), with an accuracy of ± 0.05 V

2-3 entering the calibration mode

To enter the calibration mode, press the * 3 key and the "Enter" key simultaneously. The instrument will display the following menu of calibration modes:

Calibration: Batt mV RTD RJC Exit

The cursor can be moved to the right by pressing the (up key) or to the left by pressing the (down key).

2-4 exiting the calibration mode

The calibration mode can be exited at any time by moving the cursor to **Exit** on the display and pressing the "Enter" key. There will be a few seconds delay after the "Enter" key is pressed until the Micromite II returns to its normal operating mode.

2-5 Important procedural information

- All calibrations should be performed *in the case*. There are no potentiometers in the instrument and calibration errors can result if the Micromite II is out of its case.
- The Micromite II should be turned on for at least *30 minutes* before any calibration is performed. If the instrument has been subject to a recent large change in ambient temperature (e.g. if it were stored in your car trunk on a hot or cold day and then brought into a building), it should be turned on for at least *1 hour* before any calibration is performed.
- If, during the calibration, the Micromite II displays:

Reset!
Please Turn Off


This is a warning message informing you that an improper procedure has been performed.

Recheck all connections, inputs and procedures. Turn the instrument off and on again. Repeat the procedure. If the instrument still displays the same message, it needs repair.

- Each of the items in the calibration menu can be performed independently of the others. Any number of calibration items can be performed in one calibration session. However, the RJC calibration should be done only if you are certain that the mV portion of the Micromite II is in calibration. Otherwise, *serious RJC calibration errors can occur*.

- All calibrations, except for the battery trip point calibration, should be performed while the instrument is powered only by the internal batteries or the supplied AC adapter. Any other power source (e.g. an adjustable power supply) could cause calibration errors.
- Never remove the power while in the calibration mode. The calibration constants that are calculated during each calibration are only stored upon exiting the calibration mode. Removing power before exiting the calibration mode will result in the loss of all newly calculated constants.

2-6 battery trip point calibration



BATTERY CALIBRATION
Figure 2.1

Equipment needed: adjustable power supply Note; all voltage inputs should be through the ac adapter

Connect the power supply to the instrument through the ac adapter jack as shown in Figure 2.1.

Adjust the supply to 9 volts. Enter the calibration mode, as described above. Move the cursor to **Batt** and press "Enter." The display will indicate:

Input:
6.20 Volts

Adjust the power supply to 6.2 volts (± 0.05 volts) and press "Enter". The display will indicate **WAIT!** for 15 seconds while it is calibrating. When this step is completed, the Micromite II will display:

Input:
5.70 Volts

Adjust the power supply to 5.7 volts (± 0.05 volts) and press "Enter". The display will indicate **WAIT!** for 15

seconds while it is calibrating. When the instrument is done calibrating, it will display the calibration menu with the cursor pointing to **mV**. We suggest you **EXIT** the calibration mode. Then turn the Micromite off and restore power with the internal batteries or the AC adapter supplied.

While it is possible to do the other calibrations with the adjustable power supply connected to the instrument, we recommend you use the batteries or the AC adapter.

2-7 millivolt calibration

Equipment needed: mV standard, terminal short


Enter the calibration mode, move the cursor to **mV** and press "Enter". The display will indicate:

Input:
0.000 mV


Connect the input as shown in Figure 2.2, using the terminal short. Press "Enter". The Micromite II will indicate **WAIT!** for 15 seconds while it is calibrating. When the calibration is complete, the instrument will display:

Input:
99.000 mV

Connect the mV standard input as shown in Figure 2.3. We recommend you make these connections using low emf connectors (gold /copper). Input 99.000 mV (± 0.0005 mV). Press "Enter". The Micromite II will indicate **WAIT!** for 15 seconds while it is calibrating. When the calibration is complete, the instrument will display the calibration menu with the cursor pointing to **RTD**.



0.000 mV CALIBRATION
Figure 2.2




99.000 mV CALIBRATION
Figure 2.3

2-8 RTD calibration

Equipment needed: 400.00 Ω standard

Enter the calibration mode, move the cursor to **RTD** and press "Enter". The display will indicate:



RTD CALIBRATION
Figure 2.4

Input:
400.00 Ω

Connect the 400.00 Ω ($\pm 0.005\Omega$) standard as shown in Figure 2.4. This connection must be made in the **4-Wire** configuration. Press "Enter". The Micromite II will display **WAIT!** for approx. 20 seconds. When the calibration is completed, the instrument will display the calibration menu with the cursor pointing to **RJC**.

2-9 Reference Junction compensation calibration


Equipment needed: reference thermocouple (ISA J), ice bath, adjustable mV standard

NOTE The RJC calibration should be done only if it is certain that the mV portion of the instrument is calibrated.

Enter the calibration mode, move the cursor to **RJC** and press "Enter". The display will indicate:

Input:
32°F J T/C

Connect the calibration thermocouple and the adjustable mV standard as shown in Figure 2.5. Make sure the thermocouple is placed properly in the ice bath so that it is exposed to the maximum water flow. The thermocouple should be placed in the ice bath at least 15 minutes prior to calibration.



RJC CALIBRATION
Figure 2.5

NOTE Avoid touching the end of the thermocouple when connecting it to the instrument. Body heat can cause an erroneous calibration.

Allow at least 1-2 minutes for the thermocouple to stabilize after connecting it to the instrument. Use the adjustable mV source to take out the error in the reference thermocouple. Press "Enter". The Micromite II will display **WAIT!** while it is calibrating. This calibration can take as long as 30 seconds. When the calibration is complete, the instrument will display the calibration menu with the cursor pointing to **Exit**.

section 3 warranty

Thermo Electric Co. warrants each of its instruments to be free from defects in material and workmanship for a period of two years, commencing on the date of shipment from Thermo Electric Co.

The liability of the seller is limited to the repair and replacement of the product only if failure occurs during the warranty period and factory inspection shows no external effects or customer repair altered the functioning of the instrument.

The instrument is to be returned to Thermo Electric Co. or the nearest Thermo Electric Authorized Service Center, freight prepaid, via the most economical surface transportation method, after authorization by Thermo Electric Co. All charges for handling, reinstalling and miscellaneous expenses incurred will be the responsibility of the buyer.

When factory examination shows the returned instrument to be within the above warranty period, the equipment will be repaired or replaced, at the seller's option, at no charge to the buyer.

This warranty shall be rendered null and void when, in the judgement of qualified Thermo Electric Co. personnel, the equipment has been subjected to abnormal or abusive use or lack of proper care or maintenance by the buyer, or when it has been determined that environmental conditions have exceeded those specified by Thermo Electric Co.

Any alteration or repair of the instruments by the buyer or any party not authorized by Thermo Electric Co. without our specific consent, in writing, shall automatically terminate our warranty obligation.

This warranty on instruments manufactured and/or sold by Thermo Electric Co., or any service provided by us, is expressly in lieu of all other warranties expressed or implied. No warranty is made of merchantability or fitness for any particular purpose.

No agent is authorized to assume any liability for it or to make any written or oral warranties or obligations beyond those set forth herein, unless endorsed, in writing, and signed by an officer of Thermo Electric Co.

Note: Thermo Electric warrants the original and any subsequent factory calibration for a period of six months from date of shipment. This is providing the instrument has not be calibrated in the field, or required any other service.

section 4 instrument service

Thermo Electric has Instrument Service Centers throughout the United States and in Canada and Europe. For the location of the Instrument Service Center closest to you, call your Thermo Electric representative or your nearest Thermo Electric office:

United States and World Headquarters

Thermo Electric Co.
109 North 5th Street
Saddle Brook, NJ 07662
(201) 843-5800
FAX: (201) 843-7144

Eastern Region

Thermo Electric Co.
447 Market Street
Elmwood Park, NJ 07407
(201) 791-9683 or 791-9684

Southeastern Region

Thermo Electric Co.
3440 Oakcliff Road, Suite 128
Atlanta, GA 30340
(404) 451-3733
FAX: (404) 451-5822

Central Region

Thermo Electric Co.
5261 West 161st Street
Cleveland, OH 44142
(216) 433-4510 *new 1-800-766-4020*
FAX: (216) 433-1986

Southwestern Region

Thermo Electric Co.
12503 Exchange Drive, Suite 540
Stafford, TX 77477
(713) 240-1330
FAX: (713) 240-4871

Walt Malloy
109 N. 5th ST
Saddle Brook NJ
07662

Western Region

Thermo Electric Co.
7061 Vineland Avenue
North Hollywood, CA 91605
(818) 765-5276 or (213) 875-0861
FAX: (818) 765-2407

Canada

Thermo Electric (Canada) Ltd.
12 Rutherford Road South
Brampton, Ontario
Canada L6W 3J2
(416) 451-0813
FAX: (416) 451-4606

Europe


Thermo Electric International BV
Veerpolder 40,2361 KW Warmond
The Netherlands
01711-19206
FAX: 31171111653

section 5 specifications

ambient operating temperature	0° to 55°C (32° to 131°F)
storage temperature (without batteries)	-20° to 70°C (-4° to 158°F)
warm up time (time required to meet full specifications)	15 minutes under normal ambient conditions
normal mode rejection	> 50 db @ 60 Hz
common mode rejection	> 125 db with AC adapter @ 230 VRMS, 60 Hz
temperature stability	15 ppm of reading/degree (max)
input/output resolution	
thermocouples	0.1°
millivolts	0.001 mV
RTD's	0.1°
ohms	0.01Ω
input impedance	100 MΩ
input leakage current	< 10 nA
input error due to source resistance	1μV/100Ω
output impedance	≤ 0.005 ohms; output into a fixed load
output drive capability	45Ω fixed load (min) @ 100 mV output (max) 35Ω fixed load (min) @ 80 mV output (max) 15Ω fixed load (min) @ 40 mV output (max) 10Ω fixed load (min) @ 25 mV output (max)
output settling time	
thermocouples	settles to within 0.5°F in < 3 seconds
millivolts	settles to within 0.008 millivolts in < 3 seconds
RTD's	settles to final value in < 30 seconds
ohms	settles to final value in < 30 seconds
thermocouple output compensation	fully compensated for changes in ambient temperature
maximum RTD output excitation current	2 mA
maximum RTD lead resistance	
4 wire	300Ω
3 wire	150Ω
RTD input excitation current	1 mA
RJC error @ 25°C	± 0.1°F (max)
RJC compensation error	
J, K, T, E, N, Platinel II	0.02 deg/deg* (max)
R, S, B, W5/W26	0.05 deg/deg* (max)
	* deg/deg = $\frac{T \text{ deg error}}{\Delta T_{\text{amb deg}}}$

power	6 disposable AA batteries or AC adapter, 115 or or 230 VAC, 50/60 Hz
power consumption (AC)	0.5 Watts (max)
battery life (alkaline batteries)	
continuous use	50 hours (min) @ 75°F
normal use	> 70 hours @ 75°F
shelf life	> 6 months @ 75°F
case material	polycarbonate (G.E. Lexan™, Grade 141)
cover material	polypropylene
membrane keypad material	polycarbonate
weight (with batteries)	28 ounces
external dimensions	
length	8.6"
width	3.75"
depth	2.38"
display	2 lines of 16 alphanumeric characters, 5 x 7 dot matrix LCD
display update rate	2 updates/second
calibration uncertainty (Thermo Electric's instruments' traceability to NBS)	
thermocouples:	
J, K, T, E, N, Platinel II	± 0.25°F (max)
R, S, B, W5/W26	± 1.2°F (max)
millivolts	± 0.0035 mV (max)
RTD's	± 0.1°F (max)
ohms	± 0.015 Ω (max)
long term calibration stability	
thermocouples:	
J, K, T, E, N, Platinel II	± 0.1°F/month (max)
R, S, B, W5/W26	± 0.3°F/month (max)
millivolts	± 0.001 mV/month (max)
RTD's	± 0.1°F/month (max)
ohms	± 0.01 Ω/month (max)
recommended calibration interval	6 months
(period over which instrument will meet stated accuracy)	

RANGE AND ACCURACY TABLE



ISA Calibration	Available Range	Resolution	Accuracy Range(s)	Typical Error		Worst Case Error ¹
				@32°F (0°C)	@90% of span	
J ²	-346.0 to 2192.0°F	0.1°F	-346.0 to 2192.0°F	±0.0°F	±0.1°F	±0.5°F
	-210.0 to 1200.0°C	0.1°C	-210.0 to 1200.0°C	±0.0°C	±0.0°C	±0.3°C
K ²	-382.0 to 2500.0°F	0.1°F	-382.0 to -310.0°F	±0.5°F (@ -382.0°F)	N.A.	±1.0°F
			-310.0 to 2500.0°F	±0.0°F	±0.1°F	±0.5°F
	-194.4 to 1371.1°C	0.1°C	-194.4 to -190.0°C	±0.3°C (@ -194.4°C)	N.A.	±0.6°C
			-190.0 to 1371.1°C	±0.0°C	±0.0°C	±0.3°C
T ²	-340.0 to 752.0°F	0.1°F	-340.0 to 752.0°F	±0.0°F	±0.1°F	±0.5°F
	-206.7 to 400.0°C	0.1°C	-206.7 to 400.0°C	±0.0°C	±0.0°C	±0.3°C
E ²	-320.0 to 1832.0°F	0.1°F	-320.0 to 1832.0°F	±0.0°F	±0.1°F	±0.5°F
	-195.6 to 1000.0°C	0.1°C	-195.6 to 1000.0°C	±0.0°C	±0.0°C	±0.3°C
N ³	32.0 to 2372.0°F	0.1°F	32.0 to 2372.0°F	±0.0°F	±0.1°F	±0.5°F
	0.0 to 1300.0°C	0.1°C	0.0 to 1300.0°C	±0.0°C	±0.0°C	±0.3°C
W5/W26 ⁴	32.0 to 4200.0°F	0.1°F	32.0 to 4200.0°F	±0.2°F	±0.3°F	±0.7°F
	0.0 to 2315.6°C	0.1°C	0.0 to 2315.6°C	±0.1°C	±0.2°C	±0.4°C
Platinel II ⁵	-140.0 to 2543.0°F	0.1°F	-140.0 to 2543.0°F	±0.0°F	±0.1°F	±0.5°F
	-95.5 to 1395.0°C	0.1°C	-95.5 to 1395.0°C	±0.0°C	±0.0°C	±0.3°C
R ²	0.0 to 3200.0°F	0.1°F	0.0 to 32.0°F	±0.6°F	N.A.	±2.5°F
			32.0 to 3200.0°F	±0.6°F	±0.8°F	±1.7°F
	-17.8 to 1760.0°C	0.1°C	-17.8 to 0.0°C	±0.4°C	N.A.	±1.4°C
			0.0 to 1760.0°C	±0.4°C	±0.5°C	±0.9°C

(continued)

ISA Calibration	Available Range	Resolution	Accuracy Range(s)	Typical Error		Worst Case Error ¹
				@32°F (0°C)	@90% of span	
S ²	0.0 to 3200.0°F	0.1°F	0.0 to 32.0°F 32.0 to 3200.0°F	±0.6°F ±0.6°F	N.A. ±0.8°F	±2.5°F ±1.7°F
	-17.8 to 1760.0°C	0.1°C	-17.8 to 0.0°C 0.0 to 1760.0°C	±0.4°C ±0.4°C	N.A. ±0.5°C	±1.4°C ±0.9°C
B ²	1000.0 to 3300.0°F	0.1°F	1000.0 to 3300.0°F	N.A.	±0.8°F	±1.7°F
	537.8 to 1815.6°C	0.1°C	537.8 to 1815.6°C	N.A.	±0.5°C	±0.9°C
RTD in ⁶	-320.0 to 1500.0°F	0.1°F	-320.0 to 1500.0°F	±0.0°F	±0.1°F	±0.5°F
	-195.5 to 815.6°C	0.1°C	-195.5 to 815.6°C	±0.0°C	±0.0°C	±0.3°C
RTD out ^{6,7}	-320.0 to 1500.0°F	0.1°F	-320.0 to 1500.0°F	±0.1°F	±0.1°F	±0.7°F
	-195.5 to 815.6°C	0.1°C	-195.5 to 815.6°C	±0.0°C	±0.1°C	±0.4°C
(typical error @ I _{ex} = 1.0 mA)						
Ohms in	0.00 to 700.00Ω	0.01Ω	0.00 to 700.00Ω	±0.00Ω (@ 0.00Ω)	±0.01Ω	±0.05Ω
Ohms out ⁷	0.00 to 400.00Ω	0.01Ω	0.00 to 400.00Ω	±0.01Ω (typical error @ I _{ex} = 1.0 mA) (@ 0.00Ω)	±0.02Ω	±0.14Ω
mV	-9.999 to 99.999 mV	0.001 mV	-9.999 to 99.999 mV	±0.001 mV (@ 0.000 mV)	±0.001 mV	±0.005 mV

¹ At 75°F ±5°F within 6 months after calibration

² Conformity based on IPTS-68; NBS Monograph 125

³ Conformity based on NBS Monograph 161 (AWG 14)

⁴ Conformity based on Hoskins Manufacturing Co., W5/W26 T/C

⁵ Conformity based on Engelhard Platinel II T/C

⁶ 100 Ohm @ 0°C platinum RTD having an Alpha of 0.00385 with its conformity based on the DIN 4376 standard

⁷ With an excitation current between 0.1 mA and 2.0 mA



Scale	(Dimensions in inches unless noted) Dimensions: $x \pm .015$ $xy \pm .010$ $xyz \pm .005$ Flatness: $\pm .004$ Data corners and edges: 0.10 max. All dimensions in inches unless otherwise specified.			
Drawn By	Approved By	Checker	Engineer	
D. Williams			OK	
Initial	Signature			
Date	11/15/94		3/1/97	
 THERMO ELECTRIC Saddle Brook, New Jersey 07662				
ASSY E2213				
MMI STOCK UNIT ASSY				Rev

131	REVISION	DATE CHG. MADE
	SEE W. FOR LAYOUT	

MATERIAL LIST

TITLE
MICROMITE II
STOCK UNIT ASSEMBLY

TERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 2/19/81
ML 3115700000
E 22213
C DWG. NO.
SHEET 1 OF 2
ASS'Y DASH NO. & QUANTITY

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE	APPR.	ENG.	CHK.	DWN.
1	CASE ASSEMBLY		E2062	C 1					
2	DIGITAL P/C BD ASSEMBLY		E1828	C 1					
3	ANALOG P/C BD ASSEMBLY		E1786	C 1					
4	LCD & DISPLAY P/C BD ASSEMBLY		E2188	A 1					
5	MEMBRANE SWITCH		E1804	C 1					
6	LCD WINDOW		E2072	A 1					
7									
8	BATTERY, AA ALKALINE		E2189	A 6					
9	BATTERY ELIMINATOR JACK ASSEMBLY		E2064	A 1					
10	FLATWASHER, BATTERY ELIMINATOR JACK		E2183	A 1					
11									
12	STANDOFF, #4-40 x 1/2 LG MALE-FEMALE HEX		E2180	A 2					
13	SCREW, #4 F TYPE x 3/16 LG SELF-TAPPING		A7308	A 4					
14	SCREW, #4-40 x 1/4 LG BINDING HD		E1152-1	A 4					

REVISION

A ECN 30117
ITEM 11 WAS
DWN # E1078
ADDED ITEM 19
E2232 & REMOVE
IT # 74 11 86 8/1/81

B ECN 30169 CHG.
POS. OF IT # 18 IN
ASSY. 11/1/81

TE-262A

N 22213

TITLE
MICROMITE II
STOCK UNIT ASSEMBLY

THERMO ELECTRIC
Saddle Brook, New Jersey 07662

Saddle Brook, New Jersey 07662

APPR.

E2213

C | DWG. NO.

OF 2


ASSY DASH NO. & QUANTITY

DETAIL NO.		DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE	APPR.	ASS Y DASH NO. & QUANTITY
15		SCREW, #4-40 x 1" LG FLAT HD		A8793-3		A 2		
16		SCREW, #4-40 x 1/2" LG FLAT HD		A8793-6		A 2		
17		SERIAL NO. LABEL	E1078	E2234		A 1		
18		WARRANTY CODE LABEL		E2004		A 1		
19		INSULATOR		E2232		A 1		

REVISION

section 6 schematics & parts lists

Following are the complete schematic drawings and parts lists for the Micromite II, as of August 1, 1987.



MATERIAL LIST

TITLE

DIGITAL P.C. BOARD
MICROMITE II



HERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 11/1/86
DWN. *EE*
CKR.

ML 3115700000

ML

E1828
C DWG. NO.

ENG. R *A*

SHEET

1 OF 8

APPR.

ASS'Y DASH NO. & QUANTITY

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE														
PCB	DIGITAL P.C. BOARD		E1829		C 1														
C1	CAPACITOR - .1uf, 50V, CERAMIC		A8274-9		B 1/6														
C3																			
C4																			
C5																			
C11																			
C12																			
C14																			
C16																			
C18																			
C24																			
C25																			
C28																			
C29																			
C38																			
C39																			
C41																			
C2	CAPACITOR - 33PF, 50V, CERAMIC		A8274-10		B 3														
C9																			
C42																			
C6	CAPACITOR - 47uf, 10V, ELECT.		A9280-4		A 2														
C10																			
C7	CAPACITOR - .33uf, 50V, CERAMIC		A8274-1		B 1														
REVISION																			
A	ECN #30031 XIC5 WAS P/N A9651-1 AND R7 WAS 37K5 XIC15 WAS XIC7 66 12/10/86																		
B	ECN 3006R SEE ECN 66 2/24/86																		
C	ECN 30106 SEE ECN 66 5/13/87																		
D	ECN 30130 IC3 WAS P/N E1842-3, R29 WAS P/N A5717- 58 86 4/28/89																		

MATERIAL LIST

TITLE

DIGITAL P.C. BOARD
MICROMITE II

TERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 11/1/76
DWN. *EE*

CKR.

ENG. *RF*

APPR.

ML

E1828

DWG. NO.

SHEET

2 OF 8

ASS'Y DASH NO. & QUANTITY

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE														
C8	CAPACITOR - 15 PF, 50V, CERAMIC		A8274-15		B 1														
C15	CAPACITOR - 6800PF, 2%, 100V, NPO		E2215-1		A 2														
C26	CAPACITOR - 10uf, 16V, ELECT.		E2152		A 1														
C17	CAPACITOR - .47uf, 50V, CERAMIC		A8274-2		B 1														
C13	CAPACITOR - 1uf, 50V, ELECT.		E2097-1		A 2														
C20	CAPACITOR - 22uf, 16V, ELECT.		A9285		A 1														
C22	CAPACITOR - 2.2uf, 50V, ELECT.		E1968		A 1														
C23	CAPACITOR - .1uf, 50V, MYLAR		A8957		A 1														
C27	CAPACITOR - 4.7uf, 25V, ELECT.		A9280-1		A 1														
C30	CAPACITOR - 560PF, 50V, CERAMIC		A8710-2		B 1														
C31	CAPACITOR - 470uf, 50V, ELECT.		E1678		B 1														
C32	CAPACITOR - 220uf, 16V, ELECT.		E2153		A 3														
C33																			
C40																			

REVISION

MATERIAL LIST

TITLE

DIGITAL P.C. BOARD
MICROMITE II

THERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 11/16
DWN. *EC*

CHK.

ENG. *RF*

APPR.

ML
3 OF 8

E1828
DWG. NO.

SHEET

ASS'Y DASH NO. & QUANTITY

DETAIL NO.

DESCRIPTION

MAT'L

DWG. NO.

REV. DWG. SIZE

C34 CAPACITOR - 220 μ f, 6.3V, ELECT.

A9280-3

A 2

C36 CAPACITOR - 470 μ f, 6.3V, ELECT.

A9280-2

A 2

C82 DIODE - 1N914

A6789

A 4

C83

C84

C85

C86 DIODE, SCHOTKY - MBR140P

E2035

A 1

X1 CRYSTAL - 8 MHz

E2162

A 1

Q1 TRANSISTOR - 2N3906

A8591

A 2

Q2 TRANSISTOR - 2N3904

A8590

A 2

Q4 TRANSISTOR - 1N2222 HM

E2163

A 1

Q5 TRANSISTOR - 1P0300L

E2151

A 1

REVISION

MATERIAL LIST

TITLE
DIGITAL P.C.B.D.
MICROMITE II



THERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 11/1/88	ML	E1828
DWN. <i>EC</i>		C DWG. NO.
CHKR.		
ENG. <i>RL</i>	SHEET	4 OF 8
APPR.	ASS'Y DASH NO. & QUANTITY	

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE														
IC1	INTEGRATED CIRCUIT - 87C51	E2138-0	E2138-1		A 1														
IC2	INTEGRATED CIRCUIT - 87C51	E2138-0	E2138-2		A 1														
IC3	INTEGRATED CIRCUIT - 27C64	E1482-0	E1482-3		A 1														
IC4	INTEGRATED CIRCUIT - MC14503BCP		H9893		A 1														
IC5	INTEGRATED CIRCUIT - X2444/110		E2154		A 1														
IC6	INTEGRATED CIRCUIT - TLC271CP		E1850		A 1														
IC7	INTEGRATED CIRCUIT - MC14538BCP		E1953		A 1														
IC8	INTEGRATED CIRCUIT - MC74HC4050N		E2155		A 1														
IC9	INTEGRATED CIRCUIT - MC74HC00N		E1266		A 1														
IC10	INTEGRATED CIRCUIT - MC14538BCP		E1953		A 1														
IC12	INTEGRATED CIRCUIT - SA174 HC590N		E2157		A 1														
IC13	INTEGRATED CIRCUIT - MC74HC74N		E2144		A 1														
IC11	INTEGRATED CIRCUIT - HCP42530		H9920		A 2														
IC14																			

REVISION

MATERIAL LIST

TITLE
DIGITAL P.C.B.D.
MICROMITE II

DATE: 11/1/86
DWN. *AB*
CKR.
ENG. *RR*
APPR.

ML
E1828
C DWG. NO.

THermo ELECTRIC
Saddle Brook, New Jersey 07662

SHEET 5 OF 8
ASS'Y DASH NO. & QUANTITY

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE														
IC15	INTEGRATED CIRCUIT-MC14093BCP		E2158		A 1														
IC16	INTEGRATED CIRCUIT-MM74HC374N		E2026		A 1														
IC17	INTEGRATED CIRCUIT-ICL766+ACPA		E2159		A 1														
IC18	INTEGRATED CIRCUIT-ICL7660CPA		E2160		A 2														
IC19																			
IC20	INTEGRATED CIRCUIT-LP2931CN		E2161		A 2														
IC21																			
R1	RESISTOR-22K, 5% CARB.		A5719-151		B 4														
R9																			
R11																			
R30																			
R2	RESISTOR-100K, 5% CARB.		A5717-88		B 3														
R3																			
R27																			
R25	RESISTOR-680K, 5% CARB.		A5719-164		B 1														
R4	RESISTOR-1 MEG, 5% CARB.		A5719-32		B 1														
R6	RESISTOR-160-12, 5% CARB.		A5717-127		B 2														
R12																			

REVISION

1

MATERIAL LIST

TITLE

DIGITAL P.C. BD.
MICROMITE II

TE

THERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 4/1/86
DWN. *CB*

ML *E1828*
C/DWG. NO.

SHEET 6 OF 8

APPR.

ASS'Y DASH NO. & QUANTITY

DETAIL NO.

DESCRIPTION

MAT'L

DWG. NO.

REV.

DWG. SIZE

☒

R7 RESISTOR - 33K, 5%, CARB.

A5719-110

B 1

R8 RESISTOR - 4.21K, 1%, M.F.

A8688-313

B 1

R10 RESISTOR - 5.36K, 1%, M.F.

A8688-50

B 1

R13 RESISTOR - 3.3K, 5%, CARB.

A5719-123

B 1

R14 RESISTOR - 51K, 5%, CARB.

A5717-86

B 1

R15 RESISTOR - 71K, 5%, CARB.

A5719-162

B 1

R16 RESISTOR - 180.5K, 5%, CARB.

A5719-159

B 1

R17 RESISTOR - 47K, 5%, CARB.

A5719-92

B 1

R18 RESISTOR - 47K, 5%, M.F.

A8688-46

B 1

R19 RESISTOR - 33K, 5%, CARB.

A5719-110

B 1

R20 RESISTOR - 24.9K, 1%, M.F.

A8688-68

B 1

R21 RESISTOR - 100K, 1%, M.F.

A8688-26

B 1

R22 RESISTOR - 20.5K, 1%, M.F.

A8688-71

B 1

R23 RESISTOR - 69.2K, 1%, M.F.

A8688-404

B 1

REVISION

TE-262A

N E1828

MATERIAL LIST

TITLE

DIGITAL P.C. BOARD
MICROMITE II

HERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 11/19/80

DWN. *ML*

CHK.

ENG. *RL*

APPR.

ML

E1828
DWG. NO.

SHEET

7 OF 8

ASS'Y DASH NO. & QUANTITY

DETAIL

DESCRIPTION

MAT'L

DWG. NO.

REV.

DWG. SIZE

SHEET

7 OF 8

ASS'Y DASH NO. & QUANTITY

R24 RESISTOR - 10K, 1% M.F.

A8688-15

B 1

R26 RESISTOR - 510K, 5% CARBON

A5719-147

B 1

R21 RESISTOR - 10K, 5% CARBON

A5719-102

B 1

A5719-33

B 1

R32 RESISTOR - 200K, 5% CARBON

A5719-163

B 2

R33

R34 RESISTOR - 39K, 5% CARBON

A5719-93

B 1

R41 RESISTOR NETWORK - 100K, 10% SLIP

A9223

A 2

R42

X11 SOCKET, 40 PIN DIP

A92241

A 2

X12

X13 SOCKET, 28 PIN DIP

A8900

A 1

X15 SOCKET, 8 PIN DIP

A6724

A 1

J1 SOCKET STRIP, 17 PINS

E2191-1

A 1

J2 SOCKET STRIP, 12 PINS


E2191-2

A 1

REVISION

TE-262A

E1828



LET	REVISION	DATE
	SEE M.I. FOR FIRST CORRECTION	

ASSEMBLY DWG.

FOR COMPLETE LIST OF MAT'L'S. SEE M L E1786

Scale Tolerance (unless otherwise noted) Dimensions: $\pm .015$ in $\pm .010$ mm $\pm .005$ Fractional: $\pm .004$ Heat treatment: as specified Material: unless otherwise specified	Fig. No. & A Approved By Initial Date	Design Drawn Checked Project Scale	AMALOG P.C. E.D. INFORMIT TT
 THERMO ELECTRIC Saddle Brook, New Jersey 07632	 E 1786		

ANALOG P.C. BOARD
MICROMITE II

THERMO ELECTRIC
Saddle Brook, New Jersey 07662

Saddle Brook, New Jersey 07662

DATE: 11/10/00

DATE: 11/26/2011

CKB

ENG. C/

APPENDIX

SHEET

2 OF 3

M

E 1786

☒ DWG NO

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	APPR.	ASS'Y DASH NO. & QUANTITY
C2	CAPACITOR - .015uf, 50V CERAMIC		A8274-6	B 1		
C7	CAPACITOR - 1uf, 100VDC, MET POLY.		E 2165	A 2		
C39						
C8	CAPACITOR - .47uf, 50V, CERAMIC		A8274-2	B 4		
C44						
C45						
C46						
C9	CAPACITOR - 22uf, 16V, ELECT		A9285	A 1		
C16	CAPACITOR - 560PF, 50V, CERAMIC		A8710-2	B 3		
C20						
C22						
C19	CAPACITOR - 33PF, 50V, CERAMIC		A8274-10	B 3		
C48						
C49						
C23	CAPACITOR - 100PF, 50V, CERAMIC		A8710-7	B 3		
C24						
C29						
C32	CAPACITOR - 470PF, 50V, CERAMIC		A8274-4	B 3		
C42						
C43						


REVISION

TE-262A

MATERIAL LIST

TITLE

ANALOG P.C. BOARD
MICRO MITE II



THERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 11/20/86
DWN. *EJB*
CKR.

ML *E1786*
C DWG. NO.

ENG. CK

SHEET 3 OF 8

APPR.

ASS'Y DASH NO. & QUANTITY

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE														
C27	CAPACITOR - 150PF, 50V, CERAMIC		A8710-1		13 1														
C25	CAPACITOR - 2.2uf, 25V, TANTALUM		E1679		A 1														
CR1	DIODE - 1N914		A6789		A 6														
CR2																			
CR3																			
CR4																			
CR5																			
CR6																			
IC1	INTEGRATED CIRCUIT - MC14053BCP		A9185		A 2														
IC2																			
IC3	INTEGRATED CIRCUIT - MC14051BCP		E2142		A 1														
IC4	INTEGRATED CIRCUIT - MC14052BCP		E1851		A 1														
IC5	INTEGRATED CIRCUIT - TLC271L2CP		E1852		A 2														
IC6																			
IC7	INTEGRATED CIRCUIT - LT1019CN8		E2143-1		A 1														
IC8	INTEGRATED CIRCUIT - LT1019ACN8		E2143-2		A 1														
IC14	INTEGRATED CIRCUIT - TLC271LCP		E1850		A 1														

REVISION

MATERIAL LIST

TITLE

ANALOG P.C.B.D.
MICROMITE II

TE

THERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 1/4/76

DWN. *ML*

CHKR.

ENG. CLK

APPR.

ML

E1786
DWG. NO.

SHEET

4 OF 8

ASS'Y DASH NO. & QUANTITY

DETAIL NO.

DESCRIPTION

MAT'L

DWG. NO.

REV.

DWG. SIZE

IC9 INTEGRATED CIRCUIT-AT1012C408

A9154

A 5

IC10

IC11

IC12

IC13

IC15 INTEGRATED CIRCUIT-TLC372CP

E2036

A 1

IC16 INTEGRATED CIRCUIT-HCPL2530

A9920

A 1

IC17 INTEGRATED CIRCUIT-MC74HC74N

E2144

A 2

IC18

IC19 INTEGRATED CIRCUIT-TLC5556P

E2145

A 1

IC20 INTEGRATED CIRCUIT-MC74HC164

E2146

A 1

IC21 INTEGRATED CIRCUIT-MC74HC595

E2147

A 1

IC22 INTEGRATED CIRCUIT-DAC1232

E1240

A 1

IC23 INTEGRATED CIRCUIT-PM-7528

E2148

A 1

IC24 INTEGRATED CIRCUIT-LN335A2

E2149

A 1

Q1 TRANSISTOR-2N3906

A8591

A 3

Q4

Q5

REVISION

TE-262A

ML 1786

MATERIAL LIST

TITLE

ANALOG P.C. BOARD
MICROMITE II



THERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 11/1/86
DWN. *EE*
CKR. *EE*

ENG. *CL*
SHEET 5 OF 8
ML
E1786
DWG. NO.

APPR.

ASSY DASH NO. & QUANTITY

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE														
Q2	TRANSISTOR - 2N4393		E2150		A 3														
Q3																			
Q6																			
Q7	TRANSISTOR - VPO 300L		E2151		A 1														
Q8	TRANSISTOR - VNO 300L		E2164		A 1														
R1	RESISTOR NETWORK - 125 K, 6PIN SIP		E2131		A 1														
R2	RESISTOR NETWORK - 8PIN SIP		E2132		A 1														
R3	RESISTOR NETWORK - 4PIN SIP		E2133		A 1														
R4	RESISTOR NETWORK - 4PIN SIP		E2134		A 1														
R5	RESISTOR NETWORK - 7.5K, 8PIN SIP		E2135		A 1														
R6	RESISTOR NETWORK - 8PIN SIP		E2136		A 1														
R1	RESISTOR - 1.5 K, 1% M.F.		A8686-43		B 1														
R2	RESISTOR - 10 K, 1% M.F.		A8688-15		B 2														
R3	RESISTOR - 6.65 K, 1% M.F.		A8688-266		B 1														
R4	RESISTOR - 100 M Ω , 5% CARB.		A5719-134		B 1														

REVISION

ANALOG P. C. BOARD
MICROMITE II

THERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE:	11/24/16
DWN.	LC
CKR.	
ENG.	CK
APBR	

С.К.Р.

ENG. C.K.

APPR.

SHEET	
1	

OF

E-1786
C DWG. NO.

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE
R5	RESISTOR - 133K, 1%, M.F.		A8688-56	B 1	
R6	RESISTOR - 1Meg., 1%, M.F.		A8688-201	B 1	
R7	RESISTOR - 2752, 1%, M.F.		A8688-397	B 1	
R8	RESISTOR - 49.9K, 1%, M.F.		A8688-46	B 3	
R9					
R12					
R10	RESISTOR - 10M, 1%, M.F.		A8688-398	B 3	
R21					
R30					
K13	RESISTOR - 470K, 1%, M.F.		A8688-399	B 2	
R25					
R14	RESISTOR - 15K, 1%, M.F.		A8688-18	B 2	
K26					
R15	RESISTOR - 180-52, 5%, CARB.		A5719-159	B 1	
K16	RESISTOR - 100K, 5%, CARB.		A5719-88	B 2	
R44					
S17	RESISTOR - 15K, 5% CARB.		A5719-156	B 1	

TE-262A

ML 51786

MATERIAL LIST

TITLE

ANALOG P. C. BOARD
MICROMITE II



THERMO ELECTRIC
Saddle Brook, New Jersey 07662

DATE: 10/10/80

DWN. *GC*

CKR.

ENG. *CL*

APPR.

ML

E1786

DWG. NO. *2*

SHEET

7 OF 8

ASS'Y DASH NO. & QUANTITY

DETAIL NO.	DESCRIPTION	MAT'L	DWG. NO.	REV.	DWG. SIZE														
R18	RESISTOR - 100K, 1%, M.F.		A8688-26		B 3														
R22																			
R23																			
R19	RESISTOR - 24.9K, 1%, M.F.		A8688-68		B 2														
R42																			
R20	RESISTOR - 410Ω, 1%, PTF		E2141-1		A 1														
R24	RESISTOR - 21.92K, 1%, M.F.		A8688-239		B 2														
R28																			
R27	RESISTOR - 33.3K, 1%, M.F.		A8688-61		B 1														
R21	RESISTOR - 54.22K, 1%, PTF		E2141-4		A 1														
R31	RESISTOR - 165.1K, 1%, PTF		E2141-5		A 1														
R32	RESISTOR - 560K, 1%, M.F.		A8688-400		B 1														
R33	RESISTOR - 110K, 1%, M.F.		A8688-55		B 1														
R34	RESISTOR - 280K, 1%, M.F.		A8688-357		B 1														
R35	RESISTOR - 40.52, 1%, M.F.		A8688-402		B 1														
R36	RESISTOR - 11K, 1%, M.F.		A8688-53		B 1														
REVISION																			

TE-262A

ML E1786



MA24274